

INDASH by PANAVISE®

I-751101707

Page 1 of 1

MOUNTING LOCATION:

Right Side of Radio Cavity KR

TOOLS REQUIRED:

Dash Tool - Plastic (Wide)

Phillips screwdriver

PARTS INCLUDED:

(1)S7-1892 Mount

(3)A - #8x9/16" Needle Pt. Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

MODELS & YEARS

PART#: **751101707**

MFG: **CHEVY / GMC**

(With Air Vents Above Radio)

CHEVY-1500 Silverado(Vents Above Radio)07-13

2500/3500HD Silverado (Vents Above Radio)07-14

Tahoe 07-14, Surburban 07-14, Avalanche 07-13,

GMC-1500 Sierra 07-13, 2500/3500HD Sierra 07-14

Sierra Denali 07-14,Yukon 07-14

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: These clips are tight, and will take some force to remove them. Also, the top strip above the bezel is a part of the bezel. With a Wide Plastic Dash Tool, CAREFULLY! remove the radio/climate control bezel by starting at the right side by the corners pulling to release (1) clip at a time. Continue working your way around the bezel until all (7) clips are released. Set the bezel aside.

STEP #2 Place InDash by PanaVise Mount on to the right side edge of the dash cavity. Be sure the edge of the mount is flat against the side. Install the (3) screw provided into the dash. Press the mount to the right before tightening.

STEP #3: Replace the bezel carefully.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Mounting location can vary, as long as mount is flush to side and bottom edge of dash



InDash Installed Showing Location



05-19-15