

Maxim > Design Support > Technical Documents > Tutorials > A/D and D/A Conversion/Sampling Circuits > APP 4701 Maxim > Design Support > Technical Documents > Tutorials > Amplifier and Comparator Circuits > APP 4701 Maxim > Design Support > Technical Documents > Tutorials > Hot-Swap and Power Switching Circuits > APP 4701

Keywords: PLC, programmable logic controller, industrial controls, fieldbus, analog input, analog output, Profibus, factory automation, electronic components

TUTORIAL 4701

Introduction to Programmable Logic Controllers (PLCs) and the Operational Function of Main System Modules

By: Hugh Wright May 10, 2010

Abstract: This tutorial offers an in-depth introduction into programmable logic controllers (PLCs). The article starts with an overview of the history and the role PLCs in factory automation. The basic principles of PLC operation are discussed. The core modules of an industrial-control system are examined: the analog input function, analog output functions, the distributed control (fieldbus) interface, digital inputs and outputs (I/Os), the CPU, and isolated power. Functional block diagrams and recommended devices are included for each function.

Overview

Programmable logic controllers (PLCs) have been an integral part of factory automation and industrial process control for decades. PLCs control a wide array of applications from simple lighting functions to environmental systems to chemical processing plants. These systems perform many functions, providing a variety of analog and digital input and output interfaces; signal processing; data conversion; and various communication protocols. All of the PLC's components and functions are centered around the controller, which is programmed for a specific task.



The basic PLC module must be sufficiently flexible and configurable to meet the diverse needs of different factories and applications. Input stimuli (either analog or digital) are received from machines, sensors, or process events in the form of voltage or current. The PLC must accurately interpret and convert the stimulus for the CPU which, in turn, defines a set of instructions to the output systems that control actuators on the factory floor or in another industrial environment.

Modern PLCs were introduced in the 1960s, and for decades the general function and signal-path flow changed little. However, twenty-first-century process control is placing new and tougher demands on a PLC: higher performance, smaller form factor, and greater functional flexibility. There must be built-in protection against the potentially damaging electrostatic discharge (ESD), electromagnetic interference and radio frequency interference (RFI/EMI), and high-amplitude transient pulses found in the harsh industrial setting.

Robust Design

PLCs are expected to work flawlessly for years in industrial environments that are hazardous to the very microelectronic components that give modern PLCs their excellent flexibility and precision. No mixed-signal IC company understands this better than Maxim. Since our inception, we have led the industry with exceptional product reliability and innovative approaches to protect high-performance electronics from real environmental dangers, including high levels of ESD, large transient voltage swings, and EMI/RFI. Designers have long endorsed Maxim's products because they solve difficult analog and mixed-signal design problems and continue solving those problems year after year.

Higher Integration

PLCs have from four to hundreds of input/output (I/O) channels in a wide variety of form factors, so size and power can be as important as system accuracy and reliability. Maxim leads the industry in integrating the right features into ICs, thereby reducing the overall system footprint and power demands and making designs more compact. Maxim has hundreds of low-power, high-precision IC's in the smallest available footprints, so the system designer can create precision products that meet strict space and power requirements.

Factory Automation, a Short History

Assembly lines are a relatively new invention in human history. There have likely been many parallel inventions in many countries, but here we will mention just a few highlights from the U.S.

Samuel Colt, the U.S. gun manufacturer, demonstrated interchangeable parts in the mid-1800s. Previously each gun was assembled with individually made pieces that were filed to fit. To automate that assembly process, Mr. Colt placed all the pieces for ten guns in separate bins and then assembled a gun by randomly pulling pieces from the bins. Early in the twentieth century Henry Ford expanded mass-production techniques. He designed fixed-assembly stations with cars moving between positions. Each employee learned just a few assembly tasks and performed those tasks for days on end. In 1954 George Devol applied for U.S. Patent 2,988,237, which enabled the first industrial robot named Unimate. By the late 1960s General Motors® used a PLC to assemble automobile automatic transmissions. Dick Morley, known as the "father" of the PLC, was involved with the production of the first PLC for GM®, the Modicon. Morley's U.S. Patent 3,761,893 is the basis of many PLCs today. (For more information on the above four inventors, please see: www.wikipedia.org/; for their patents, search: http://patft.uspto.gov/netahtml/PTO/srchnum.htm).

Basic PLC Operation

How simple can process control be? Consider a common household space heater.

The heater's components are enclosed inside one container, which makes system communications easy. Expanding on this concept is a household forced-air heater with a remote thermostat. Here the communication paths are just a few meters and a voltage control is typically utilized.

Think now beyond a small, relatively simple process-control system. What controls and configuration are necessary in a factory?

The resistance of long wires, EMI, and RFI make voltage-mode control impractical. Instead, a current loop is a simple, but elegant solution. In this design wire resistance is removed from the equation because Kirchhoff's law tells us that the current anywhere in the loop is equal to all other points in the loop. Because the loop impedance and bandwidth are low (a few hundred ohms and < 100Hz), EMI and RFI spurious pickup issues are minimized. A PLC system is useful for properly controlling such a factory system.



A household electric heater serves as a simple example of process control.



Longer-range factory communications.

Current Communication for PLCs

Current-control loops evolved from early twentieth-century teletype impact printers, first as 0–60mA loops and later as 0–20mA loops. Advances in PLC systems added 4–20mA loops.

A 4–20mA loop has several advantages. Older discrete component designs required careful design calculations; circuitry was comparatively large compared to today's integrated 4–20mA ICs. Maxim has introduced several 20mA devices, including the MAX15500 and MAX5661, which greatly simplify the design of a 4–20mA PLC system.

Any measured current-flow level indicates some information. In practice, the 4–20mA current loops operate from a 0mA to 24mA current range. However, the electrical current ranges from 0mA to 4mA and 20mA to 24mA are used for diagnostics and system calibration. Since current levels below 4mA and above 20mA are used for diagnostics, one might conclude that readings between 0mA and 4mA could indicate a broken wire in the system. Similarly, a current level between 20mA and 24mA could indicate a potential short circuit in the system.

An enhancement for 4–20mA communications is the highway-addressable remote transducer (HART® system) which is backward compatible with 4–20mA instrumentation. A HART system allows two-way communications with smart, microprocessor-based, intelligent field devices. The HART protocol allows additional digital information to be carried on the same pair of wires with the 4–20mA analog current signal for process-control applications.

PLCs can be described by separating them into several functional groups. Many PLC manufacturers will organize these functions into individual modules; the exact content of each of these modules will likely be as diverse as are the applications. Many modules have multiple functions that can interface with multiple sensor interfaces. Yet other modules or expansion modules are often dedicated to a specific application such as a resistance temperature detector (RTD), sensor, or thermocouple sensor. In general, all modules have the same core functions: analog input, analog output, distributed control (e.g., a fieldbus), interface, digital input and outputs (I/Os), CPU, and power. We will examine each of these core functions in turn, and leave sensors and sensor interfaces for a separate section.



Simplified PLC block diagram. For a list of Maxim's recommended PLC solutions, please go to: www.maximintegrated.com/plc.

General Motors is a registered trademark of General Motors LLC. GM is a registered trademark of General Motors LLC. HART is a registered trademark of the HART Communication Foundation.

Related Parts		
DS28E01-100	1Kb Protected 1-Wire EEPROM with SHA-1 Engine	Free Samples
DS3600	Secure Supervisor with 64B Nonimprinting, Battery- Backed Encryption Key SRAM	Free Samples
DS8500	HART Modem	Free Samples
MAX1300	8- and 4-Channel, $\pm 3~x~V_{REF}$ Multirange Inputs, Serial 16-Bit ADCs	Free Samples
MAX1301	8- and 4-Channel, $\pm 3~x~V_{REF}$ Multirange Inputs, Serial 16-Bit ADCs	Free Samples
MAX1302	8-Channel, $\pm V_{REF}$ Multirange Inputs, Serial 16-Bit ADC	Free Samples
MAX1303	4-Channel, $\pm V_{REF}$ Multirange Inputs, Serial 16-Bit ADC	Free Samples
MAX13430E	RS-485 Transceivers with Low-Voltage Logic Interface	Free Samples
MAX13433E	RS-485 Transceivers with Low-Voltage Logic Interface	Free Samples

MAX13442E	±80V Fault Protected RS-485 Half-Duplex Transceiver with Foldback Current Limit	Free Samples
MAX13443E	±80V Fault Protected RS-485 Half-Duplex Transceiver with Foldback Current Limit	Free Samples
MAX13448E	±80V Fault-Protected, Full-Duplex RS-485 Transceiver	Free Samples
MAX13450E	RS-485 Transceivers with Integrated $100\Omega/120\Omega$ Termination Resistors	Free Samples
MAX13451E	RS-485 Transceivers with Integrated $100\Omega/120\Omega$ Termination Resistors	Free Samples
MAX13485E	Half-Duplex RS-485/RS-422 Transceivers in μ DFN	Free Samples
MAX13486E	Half-Duplex RS-485/RS-422 Transceivers in μ DFN	Free Samples
MAX14752	8-Channel/Dual 4-Channel 72V Analog Mux	Free Samples
MAX14753	8-Channel/Dual 4-Channel 72V Analog Mux	Free Samples
MAX14770E	High-ESD PROFIBUS RS-485 Transceiver	Free Samples
MAX14824	IO-Link Master Transceiver	Free Samples
MAX14830	Quad Serial UART with 128-Word FIFOs	
MAX15046	40V, High-Performance, Synchronous Buck Controller	Free Samples
MAX15048	Triple-Output Buck Controllers with Tracking/Sequencing	Free Samples
MAX15049	Triple-Output Buck Controllers with Tracking/Sequencing	Free Samples
MAX15500	Industrial Analog Current/Voltage Output Conditioners	Free Samples
MAX15501	Industrial Analog Current/Voltage Output Conditioners	Free Samples
MAX256	3W Primary-Side Transformer H-Bridge Driver for Isolated Supplies	Free Samples
MAX3107	SPI/I ² C UART with 128-Word FIFOs	Free Samples
MAX3440E	±15kV ESD-Protected, ±60V Fault-Protected, 10Mbps, Fail-Safe RS-485/J1708 Transceivers	Free Samples
MAX3444E	±15kV ESD-Protected, ±60V Fault-Protected, 10Mbps, Fail-Safe RS-485/J1708 Transceivers	Free Samples
MAX3535E	+3V to +5V, 2500V _{RMS} Isolated RS-485/RS-422 Transceivers with ±15kV ESD Protection	Free Samples
MAX4238	Ultra-Low Offset/Drift, Low-Noise, Precision SOT23 Amplifiers	Free Samples
MAX4239	Ultra-Low Offset/Drift, Low-Noise, Precision SOT23 Amplifiers	Free Samples
MAX5033	500mA, 76V, High-Efficiency, MAXPower Step-Down DC- DC Converter	Free Samples

MAX5035	1A, 76V, High-Efficiency MAXPower Step-Down DC-DC	Free Samples
MAX5069	High-Frequency, Current-Mode PWM Controller with Accurate Oscillator and Dual FET Drivers	Free Samples
MAX5079	ORing MOSFET Controller with Ultra-Fast 200ns Turn- Off	Free Samples
MAX5080	1A, 40V, MAXPower Step-Down DC-DC Converters	Free Samples
MAX5081	1A, 40V, MAXPower Step-Down DC-DC Converters	Free Samples
MAX5134	Pin-/Software-Compatible, 16-/12-Bit, Voltage-Output DACs	Free Samples
MAX5135	Pin-/Software-Compatible, 16-/12-Bit, Voltage-Output DACs	Free Samples
MAX5136	Pin-/Software-Compatible, 16-/12-Bit, Voltage-Output DACs	Free Samples
MAX5137	Pin-/Software-Compatible, 16-/12-Bit, Voltage-Output DACs	Free Samples
MAX5167	32-Channel Sample/Hold Amplifier with Output Clamping Diodes	Free Samples
MAX5490	100k Ω Precision-Matched Resistor-Divider in SOT23	Free Samples
MAX5491	Precision-Matched Resistor-Divider in SOT23	Free Samples
MAX5492	$10k\Omega$ Precision-Matched Resistor-Divider in SOT23	Free Samples
MAX5661	Single 16-Bit DAC with Current and Voltage Outputs for Industrial Analog Output Modules	Free Samples
MAX9939	SPI-Programmable Gain Amplifier (PGA) with Input V_{OS} Trim and Output Op Amp	Free Samples
MAX9943	High-Voltage, Precision, Low-Power Op Amps	Free Samples
MAX9944	High-Voltage, Precision, Low-Power Op Amps	Free Samples
MAXQ1850	Secure Cryptographic Controller with Rapid Zeroization Technology	Free Samples

More Information

For Technical Support: http://www.maximintegrated.com/support For Samples: http://www.maximintegrated.com/samples Other Questions and Comments: http://www.maximintegrated.com/contact

Application Note 4701: http://www.maximintegrated.com/an4701 TUTORIAL 4701, AN4701, AN 4701, APP4701, Appnote4701, Appnote 4701 Copyright © by Maxim Integrated Products Additional Legal Notices: http://www.maximintegrated.com/legal